

Machine Number	Machine Model	Knob / LCM	Country	Board Type	Board Number	PCB Comments	Current Working Programmes
WHM Standard Cranes							
WMH-188	Fantasy World	2 Knob	A	Main PCB	W9803D4	2 bank	188C5
			NZ & A	Main PCB	W030934	3 bank	MA188PS (NZ&A)
			NZ	Main PCB	W070514	3 bank	
			NZ	Main PCB	W100202	3 bank	
WMH-288	Toy Soldier / Telephone or Arena (restickered)	2 Knob	NZ & A	Main PCB	W030934	3 bank	MA188PS (NZ&A)
			NZ & A	Main PCB	W070514	3 bank	
			NZ & A	Main PCB	W100202	Solid State	
WMH-288	Toy Soldier / Arena / Telephone Box / Movie Stars / Price Depot	LCM	A	Main PCB	W041157		W588M (A)
			NZ	Main PCB	W060204		D5880415 (NZ)
			NZ	Main PCB	W100411		D5880419 (A)
WMH 189L	The Claw Standard	LCM	NZ & A	Main PCB	W150104 - rev.0	Small Board	189LA101 (NZ&A)
			NZ	Main PCB	W140207		E89LN201 (NZ)
							NB1LA101 (NZ)
							N288AU00 (A)
WMH 189L	Shining Crane / The Claw	Joystick		Main PCB	W120206		E89L - 01
				Main PCB	W140207 Rev1	Small Board	E89LN201
WHM Chocolate Cranes							
WMH-188A	Chocolate Fantasy World	2 Knob	NZ	Main PCB	W9803D4	2 bank	W14C (NZ) (W1415 older chip)
WMH-288C	Chocoholic / Cool Age (A) /Chocolate Fantasy World / Chocolate Ice Age	2 Knob	NZ & A	Main PCB	W030934	3 bank	CL18810
			NZ & A	Main PCB	W070514	3 bank	LCM188D3
			A	Main PCB	W100202	Solid State	CL18813
WMH288C / WMH518	Inline extra board for Iron Claw and Cool Age to prevent the display going fuzzy.			Extra Board	W121023		
WMH-W299CL	Cool Age (NZ)	2 knob	NZ	Main PCB	W150104	2 bank	NCL-A100
WMH-288C Jumbo	Chocoholic Jumbo	2 knob	A	Main PCB	W070514-288		CL18820
WHM Jumbo Cranes							
WMH-288B1	Movie Star, Koalakrane Sports Arena Large	LCM		Main PCB	W060204		F588B104 (A) D5880415 (NZ)
				Main PCB	W100411	Solid State - Smaller board	
WMH-288B1	Prize Depot	LCM	NZ	Main PCB	W100411	Solid State - Smaller board	F588-B101 (NZ - Prize Depot)
WMH 288B1L	The Claw Large	2 knob	NZ & A	Main PCB	W150104 - rev.0		28B1A100 (A)
		LCM	NZ	Main PCB	W100411		NB1LA101 (NZ)
							F588B102????
WMH 289BIL	Shining Crane Large	2 knob	A	Main PCB	W150104		
WHM Super Jumbo Cranes							
WMH-288B	Movie Star, Prize Depot Jumbo, Toy Soldier	LCM	NZ & A	Main PCB	W060204	Relay Board	F588B003 (A)
		LCM	NZ & A	Main PCB	W100411,	Solid State	D5880415 (NZ)
WHM Iron Claw							
WMH-518	Iron Claw	LCM	NZ & A	Main PCB	W100411		W518A103 (A) W518A101 (NZ)
WMH288C / WMH518	Inline extra board for Iron Claw and Cool Age to prevent the display going fuzzy.			Extra Board	W121023		
WHM Giant Cranes							
WMH-288K	Maxi Claw	LCM	NZ & A	Main PCB	WO70202		G588KS05 588KN301
				Main PCB	W040203A or V3		CL288K10
				Claw Controller	W040316		
WMK-288KL	RGB Giant	LCM	NZ	Main PCB	WO70202		G588KS05 588KN301
WHM Double Play Cranes							
WMH-390 & 390B	WET Standard and Jumbo - Converted to plush only	2 Knob	A	Main PCB	Any of the boards		
WMH-390 & 390B	WET Standard and Jumbo		NZ & A	Main PCB	W040203A		CL3903
			A	Main PCB	W070514-390		CL288K10
			A	Main PCB	W100202-390	Solid State	W390_N3
	Win Everytime Solid State secondary pcb	A	Main PCB	W081038			
WHM Coin Changers							
WMH-918	Coin Changer			Main PCB	W040740		I918C8A
WMH-918	Coin Changer Solid State			Main PCB	W090419	New 2011	NI918C8A
WMH-918	Coin Changer Solid State			Main PCB	W090419	New 2011	NI918C6A6
WMH-918	coin changer AC pcb			Main PCB	ji528-c		
	ICT Inhibitor Board			Main PCB	W090625		
	WEIYA Inhibitor Board			Main PCB	W080619		
WMH288C / WMH518	Inline extra board for Iron Claw and Cool Age to prevent the display going fuzzy.			Extra Board	W121023		